


AMG5623 Instruction Manual

Dual System with 2x Independent Channels each of :

[Single Transmit Unit with one Bi-directional Data Channel plus one Bi-directional Alarm for a Multimode Fibre Link]



The **AMG5623** is a **DUAL** standalone system which provides two independent channels, each designed to transmit one video signal and transmit and receive one bi-directional alarm plus one data signal over one Multimode optical fibre.

The AMG5624 is designed to be powered using an AMG2001 standalone power supply.

The AMG5623 is designed to operate with two AMG5614 / AMG5614R single channel or one AMG5624 or AMG5624R dual channel video receive unit in a point to point configuration. The R suffix in the partno. indicates a rackmount configuration.

AMG Systems Ltd. reserves the right to make changes to this document without notice. The information herein is believed to be accurate. No responsibility is assumed by AMG for its use.

Page 1 of 8

Contents

Introduction	3
Unit Functional Schematic Optical Connection	
Connections	4
Video Input Connections	
Optical Connections Multimode	
Power Connection	
Data and Alarm Channel Connections	
Front Panel Indicators	5
Power LED	
Low Speed Data LEDs	
Alarm LEDs	5
Data and Alarm Channel Configuration	6
Data Channel Configuration	6
Data Interface Connections	7
Alarm Channel Configuration	
Alarm Interface Connections	7
Physical Information	8
Dimensions	
Mounting Details	8
Safety	8
Maintenance and Repair	8

Introduction


Unit Functional Schematic

The **AMG5623** provides two independent, transmit channels.

Each channel transmits one video signal plus 1 data and 1 bi-directional alarm signal to an **AMG5624** receive unit.


It also receives 1 data and 1 bi-directional alarm signal from the **AMG5624**.

The schematic diagram shows one of the two available channels of the **AMG5623**



Optical Connection

The **AMG5623** connections are illustrated in the following example which shows an **AMG5623** transmit unit together with an **AMG5624R** two channel standalone receive unit configured as a dual channel point to point system.



Connections

Video Input Connections

No. of channels	2
Connector	75 ohm BNC Socket.
Input Impedance	75 ohm terminated.
Input Level	
Frequency Response	10Hz to 7MHz.

Optical Connections Multimode

No. of Optical Connections	1 per video channel
Optical Fibre	Multimode 50/125 or 62.5/125**
Connector	SC/PC

Minimum Optical Launch Power	10dBm
Transmit Wavelength	1310nm

Minimum Optical Sensitivity	30dBm
Receive Wavelength	1510nm

Minimum Optical Dynamic Range20dB.

**Note: the transmission distance is limited by the bandwidth of the Multimode optical fibre. The optical data rate is 155Mbits/s, which may restrict operation to a maximum fibre length of 7km, although in most cases the units will operate successfully over longer fibre lengths. It is advisable however for distances greater than 7km, to have the optical fibre tested.

Power Connection

Connector Type Connector Partno Supply Voltage Maximum Power	+12 to +15 Volts DC
Data and Alarm Channel Conne	ections
No. of Data Channels	
No. of Alarms	1 bi-directional alarm per video channel.
Connectors Connector Partno	Removable 8-pin, 2.5mm, Screw Terminal Phoenix 1881383
Data Interfaces	RS-232, RS-422 or R-S485. Selected by slide switch inside enclosure. *See appropriate section on how to remove the case for access to the data switches

RS-485 – Switch Position - Top RS-422 – Switch Position - Middle RS-232 – Switch Position - Bottom

Alarm Input	Contact Closure pull-up is 330R to +3V3	
Alarm Output	Solid-state Relay, maximum 150mA at 125Vac/dc, Ron < 6.8	5Ω

AMG Systems Ltd. reserves the right to make changes to this document without notice. The information herein is believed to be accurate. No responsibility is assumed by AMG for its use.

Page 4 of 8

Front Panel Indicators

Power LED

Power / Video / Opto	Green R/G G/R Red Off	- - - -	Video present & opto sync. Opto sync. but no video present. Video present but no opto sync. No opto sync. No power applied to unit
Low Speed Data LEDs			
Data Present IN (RS485 or RS422) 0	Green Red Off	- - -	logic zero (+V, -V) present on IN+, IN- logic one (-V,V+) present on IN+, IN- tri-state off or no connection on IN+, IN-
Data Present IN (RS232)	Green Red Off	- -	logic zero (+V) present on input IN+ logic transitions present on input IN+ logic one (-V) present on input IN+

IN corresponds to the data signals being transmitted onto the optical fibre.

Data Present OUT (RS485 or RS422) Green	-	logic zero (+V,-V) present on OUT+, OUT-
Red	-	logic one (-V,+V) present on OUT+, OUT-
Off	-	tri-state off or no connection on OUT+, OUT-
Data Present OUT (RS232) Green	-	logic zero (+V) present on OUT+
Red	-	logic transitions present on OUT+
Off	-	logic one (-V) present on OUT+

OUT corresponds to the data signals being received from the optical fibre.


Alarm LEDs

Channel 1 ALARM INGreen Off	- Alarm ON / Cont - Alarm OFF / Cor	
ALARM OUT Green Off	 Alarm ON / Cont Alarm OFF / Cor 	
Channel 2 ALARM INGreen Off	- Alarm ON / Cont - Alarm OFF / Cor	
ALARM OUT Green Off	- Alarm ON / Cont - Alarm OFF / Cor	

Data and Alarm Channel Configuration

The **AMG5623** sends and receives data to/from up to two **AMG5614** single channel or one **AMG5624** dual channel receive unit or rackmount equivalent. Each physical data interface RS-485, RS-422 or RS-232 is individually selectable by the user with the corresponding slide switch mounted on the main PCB inside the enclosure.

One bi-directional alarm is also provided for each video channel. The alarm input is typically connected to a contact closure switch. The alarm output can receive an on/off signal from an **AMG5624** and is typically used to convey contact closure status.



Data Channel Configuration

Each low speed data channel provides an RS-232, RS-422 (full duplex, four wire) or RS-485 (half duplex, two wire) interface defined by the corresponding mode switch inside the enclosure. Every data channel as shipped from the factory is set up for RS-485 operation unless otherwise requested.

The data input for both the RS-485 and the RS-422 modes detects a tri-state input condition by monitoring the differential voltage level across the input. A differential level below 600mV positive or negative will be detected as a tri-state condition. A level above 600mV positive or negative will be detected as a logic 1 or logic 0 respectively. It is important therefore to terminate the RS-485 bus or the RS-422 input bus using 120Ω if a pre-bias is present on the RS-485 or RS-422 bus.

A large number of third party equipment manufacturers apply a pre-bias on their RS-485 bus. This prebias is applied by pulling one arm of the RS-485 bus high (+5 volts) and the other arm low (0 volts) using high value resistors within the third party equipment. In order to ensure that the AMG equipment detects a tri-state condition, then these resistors should have a value above 5k Ω . If the third party bias resistors are less the 750 Ω the bus can be multiple terminated as required to ensure that a tristate level is detected.

The system detects a tri-state input condition on the data channel bus when in RS-485 or RS-422 mode.

AMG Systems Ltd. reserves the right to make changes to this document without notice. The information herein is believed to be accurate. No responsibility is assumed by AMG for its use.

Page 6 of 8

AMG5623 Instruction Sheet D17091-04.doc

Data Interface Connections

Data Channels 1 and 2.

Connector	Data Channel		
Pin No.	RS-485 [switch top]	RS-422 [switch middle]	RS-232 [switch bottom]
1		IN + (A)	IN
2		IN - (B)	
3	GND	GND	GND
4			
5			
6			
7	IN/OUT + (A)	OUT + (A)	
8	IN/OUT - (B)	OUT - (B)	OUT

Note: (A) or (B) in brackets in the above table refers to RS-485 / RS-422 data specification.

Alarm Channel Configuration

The AMG5623 provides 1 bi-directional alarm output / contact closure input per video channel.

The alarm input is typically connected to a contact closure switch. An ALARM IN+ input incorporates a 330R pull-up resistor to the internal +3V3 supply.

The alarm output can receive an on/off signal from an **AMG5624** and is typically used to convey contact closure status. An alarm output uses a solid-state relay, with a maximum load current of 150mA at 125Vac/dc and Ron < 6.5Ω .

Alarm Interface Connections

Video Channels 1 & 2			
Connector	Alarm Interface		
Pin No.	Alarm IN	Alarm OUT	
1			
2			
3	GND		
4	ALARM IN +		
5		ALARM OUT -	
6		ALARM OUT +	
7			
8			

Physical Information

Dimensions

Height	132mm
Width	
Depth	
Weight	500grams

Mounting Details

The unit is designed to be mounted on a panel using 4 off 4.0mm screws, see diagram on page 1.

Safety

AMG Optical Fibre Products use Class 1 laser systems in accordance with EN 60825-2:2000.

It is always advisable to follow good practice when working with optical fibre systems. This includes:

- Do not stare with unprotected eyes or with any unapproved collimating device at fibre ends or connector faces, or point them at other people.
- Use only approved filtered or attenuating viewing aids

For other safety issues and advice on good practice associated with optical fibre systems, please see EN 60825-2:2000 or your local safety officer.

Maintenance and Repair

There are no user serviceable parts within AMG products. See unit data sheet for full specification.

In case of problem or failure, please call your local support centre or contact: **AMG Systems Ltd.** at 3 The Omega Centre, Stratton Business Park, Biggleswade, Beds., SG18 8QB, UK.

Phone	+44 (0) 1767 600 777
Technical Support	+44 (0) 1767 604 491
Email	techsupport@amgsystems.com